9299 MAC REKLAM / A18 / Romesco/791942 / 2250 REV 4500

EN Before you start

Important information

Read carefully.

Retain these instructions for future reference.

Do not exceed the maximum load on the shelves and drawers.

Don't rest, hang or stand on the shelves and drawers.

Don't use the drawers for purposes other than those for which they are designed.

Use a barrier or mat to avoid direct contact of very hot objects to the sink surface.

Commonly with 1935/2004/EC.

Important - Retain this information for future reference: read carefully

Empty the fridge and remove all items from the shelves and drawers before cleaning.

Make sure that any pre-installation work on the cooking electrical appliances and water supplies has been carried out by a suitably qualified person to comply with local regulations before installation.

Remove all packaging materials before installation.

Ensure the appliance is installed in a well-ventilated place.

Keep the appliance and its accessories out of reach of children.

Ensure the appliance is installed on a level and firm surface.

Always wear appropriate personal protective equipment when operating power tools.

Care

Wipe away any spills with a damp cloth.

Use a mild detergent and avoid abrasive cleaners or scouring pads, which could scratch the sink. Do not use chlorine, do not leave metal objects in the sink to prevent any risk of oxidation.

Never use any type of abrasive or scouring products and never use any sharp objects or tools.

Do not place hot pans or items straight from the oven on the surface of your sink.

Do not place hot objects/foods with a flat sealed bottom on the surface of the product, to prevent any damage to the surface.

Do not allow any sharp objects on the surface of your sink.

Do not allow any sharp objects to drop onto the sink, as this may damage the surface