



Einhell

PROFESSIONAL



Cordless Router / Palm Router

TP-RO 18 Set Li BL - Solo

Item No.: 4350410

Ident No.: 21011

Bar Code: 4006825662818

Thanks to the PXC rechargeable battery pack, the Einhell Cordless router/trimmer TP-RO 18 Set Li BL – Solo offers the freedom of cordless operation. The speed control electronics have been paired with a powerful brushless motor. The fine/depth adjustment and precise twin-tube guide enable high-precision working. The clamp (6 + 8 mm), spindle lock, and LED lighting combine with the soft grip handle, the chip shield, and the two-handed attachment to make work as comfortable and easy as possible. The plastic insert protects the workpieces. The edge trimmer base allows edges to be beveled. The unit is supplied with a parallel stop, compass tip, a copy sleeve, an assembly tool, an extraction adapter and a storage bag. No battery and charger.

Features & Benefits

- Member of the Power X-Change family
- Brushless motor - more power and prolonged operation
- Electronic speed control with powerful motor
- Infinitely adjustable routing depth with fine adjustment
- Depth adjustment with multi-step turret stop
- Precise twin-tube guide for exact milling
- 6 mm and 8 mm clamp for various milling cutters
- Spindle lock for easy tool change
- LED for optimum illumination of the work area
- Plastic base plate insert protects the work surface
- Ergonomic handle with Softgrip
- Chip shield guards against chips in the field of vision
- Two-hand attachment enables precise operation of the unit
- Edge router base also enables the chamfering of edges
- Including parallel stop, compass tip, guiding role and copy sleeve
- Including extractor adaptor suitable for Einhell wet & dry vacs
- Including storage case for clean and safe transport
- Supplied without a battery or charger (available separately)



Technical Data

- Voltage	18 V
- Lift height (router)	35 mm
- Lift height (palm router)	40 mm
- Drehzahl	10000 - 30000 min ⁻¹
- Clamp diameter	6 + 8 mm
- Max. milling cutter	30 mm



Logistic Data

- Product weight (kg)	1.34
- Gross weight (kg)	4.23
- Dimensions single packaging	320 x 276 x 200 mm
- Pieces per export carton	2 Pieces
- Gross weight of export carton	9.8 kg
- Dimensions export carton	570 x 340 x 220 mm
- Container quantity (20"/40"/40"HC)	1350 2720 2992



Available as special accessories



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



5,2Ah & 4A Fastcharger
PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 4,0Ah Power-X-Change Plus
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory

Battery-Running-Times



One Battery for All

cutting¹
(m)

1.5 Ah	22
2.0 Ah	29
2.5 Ah	37
3.0 Ah	44
4.0 Ah	58
5.2 Ah	77
6.0 Ah	88
8.0 Ah	118

Test setup:

1) softwood - chipboard 18 mm - Max. electronic speed