

# PHILIPS


## hue personal wireless lighting

T-connector / extension cable




HUE serial number

**A**  
**B**



- EN** Use only with Philips Hue 24V  $\equiv$  SELV IP67 LED power supply!
- DE** Verwendung nur mit Philips Hue 24V  $\equiv$  SELV IP67 LED-Stromversorgung!
- FR** Utiliser uniquement avec l'alimentation LED Philips Hue 24V  $\equiv$  SELV IP67!
- ES** Se utiliza solo con la fuente de alimentación LED Philips Hue SELV 24V  $\equiv$  IP67!
- PT** Utilize apenas com fonte de alimentação LED SELV Philips Hue de 24V  $\equiv$  IP67!
- IT** Da utilizzare solo con un alimentatore LED Philips Hue 24V  $\equiv$  IP67!



User manual  
Benutzerhandbuch  
Notice d'emploi  
Manual de usuário  
Manual do usuário  
Manuale d'uso



Signify  
I.B.R.S. / C.C.R.I. Numéro 10461  
5600 VB Eindhoven,  
the Netherlands  
000800-74454775




Signify Australia Limited  
65 Epping Road, North Ryde,  
NSW, 2113 Australia  
Toll Free number: 1300 304 404

Signify New Zealand Limited  
123 Carlton Gore Road  
Newmarket, Auckland 1023  
New Zealand  
Tel: 0800 454 448

www.philips-hue.com

© 2021 Signify Holding  
All rights reserved

4404 029 12662  
Last update: 10/2021



Sample set up, add up the wattage of the lights

$$8W + 8W + 8W + 16W = 40W$$

Choose your power supply unit (PSU)

40W PSU: Connect up to 40W of lights and 35 m of cable

100W PSU: Connect up to 100W of lights and 30 m of cable