



**1**

① Main unit  
② Main unit  
③ Screws and washers  
④ Screws and washers

**CLIFF®200**

⑤ Screws and washers  
⑥ Screws and washers

**CLIFF®400**

⑤ Screws and washers  
⑥ Screws and washers

**CLIFF®600**

⑤ Screws and washers  
⑥ Screws and washers

**2**

① Marking the main unit  
⚠️ Warning: Do not use the main unit until the installation is complete.

**3**

③ Mounting the main unit to the wall using screws and washers.

**4**

④ Connecting the power cord to the main unit.

**5**

⑤ Connecting the power cord to the outlet.

**6**

⑥ Mounting the main unit to the wall using screws and washers.

max?

⑤ Screws and washers

- 15 mm (2x, 5.8)
- 25 mm (2x, 5.8)
- 35 mm (2x, 6)
- 45 mm (2x)
- 20 mm (2x, 5.8)
- 30 mm (2x, 5.8)
- 40 mm (2x, 6)
- 50 mm (2x)

**7**

CLIFF®200/400/600

CLIFF®200

CLIFF®400

CLIFF®600

**CLIFF®200**

⑤ Screws and washers  
⑥ Screws and washers

**CLIFF®400**

⑤ Screws and washers  
⑥ Screws and washers

**CLIFF®400**

⑤ Screws and washers  
⑥ Screws and washers