



LUNAR F

MEXEN

DRZWI WNEKOWE ZE ŚCIANKĄ Z LISTWĄ



[PL] Instrukcja montażu [EN] Assembly Instructions [DE] Montageanleitung [FR] Instructions de montage [IT] Istruzioni di montaggio [ES] Instrucciones de montaje [NL] Montage-instructies [RU] Инструкция по монтажу [SV] Monteringsanvisning [NO] Monteringsanvisning [DA] Monteringsvejledning [FI] Asennusohje [CS] Montážní návod [PT] Instruções de montagem [HU] Szerelési útmutató [RO] Instrucțiuni de montaj [EL] Οδηγίες συναρμολόγησης [SK] Návod na montáž [UK] Інструкція з монтажу [HR] Upute za montažu [LT] Montavimo instrukcija [BG] Инструкция за монтаж [SL] Navodila za montažo [LV] Montāžas instrukcija [ET] Paigaldusjuhend [SR] Упутство за монтажу [IS] Samsetningarleiðbeiningar [SQ] Udhëzime për montim [MK] Инструкции за монтажа [MT] Istruzzjonijiet għall-assemblaġġ





[1]



X1

[2]



X1

[3]



X1



X1

[4]



X2

[5]



X2

[6]



X1

[7]



X2

[8]



X1

[9]



ST3.9X40

X8

[10]



Ø 8

X8

[11]



X1

[12]



X1

[13]



X1



X1

[14]



ST3.5X32

[15]



Ø 6


X2

[16]



X1

[17]



X1

X1

[18]



X2

[19]



X1

[20]



X1

[21]



X1

[22]



X1

[23]



X1



X1

[25]











X4

[26]















3M
X1

















$$X = B + C + D + 9 + 7 + 20 + 2$$








Model	A	X	B	C	D	E	F	G	H
60L+50R	1100	1092-1108	276	276	502	520	517	490	2000
65L+50R	1150	1142-1158	301	301	502	569	517	515	2000
70L+50R	1200	1192-1208	326	326	502	619	517	540	2000
75L+50R	1250	1242-1258	351	351	502	668	517	565	2000
80L+50R	1300	1292-1308	376	376	502	718	517	590	2000
85L+50R	1350	1342-1358	401	401	502	766	517	615	2000
90L+50R	1400	1392-1408	426	426	502	816	517	640	2000
95L+50R	1450	1442-1458	451	451	502	866	517	665	2000
100L+50R	1500	1492-1508	476	476	502	915	517	690	2000
60L+60R	1200	1192-1208	276	276	602	520	617	490	2000
65L+60R	1250	1242-1258	301	301	602	569	617	515	2000
70L+60R	1300	1292-1308	358	326	602	619	617	540	2000
75L+60R	1350	1342-1358	383	351	602	668	617	565	2000
80L+60R	1400	1392-1408	408	376	602	718	617	590	2000
85L+60R	1450	1442-1458	433	401	602	766	617	615	2000
90L+60R	1500	1492-1508	458	426	602	816	617	640	2000
95L+60R	1550	1542-1558	483	451	602	866	617	665	2000
100L+60R	1600	1592-1608	508	476	602	915	617	690	2000
60L+70R	1300	1292-1308	276	276	702	520	717	490	2000
65L+70R	1350	1342-1358	301	301	702	569	717	515	2000
70L+70R	1400	1392-1408	358	326	702	619	717	540	2000
75L+70R	1450	1442-1458	383	351	702	668	717	565	2000
80L+70R	1500	1492-1508	408	376	702	718	717	590	2000
85L+70R	1550	1542-1558	433	401	702	766	717	615	2000
90L+70R	1600	1592-1608	458	426	702	816	717	640	2000
95L+70R	1650	1642-1658	483	451	702	866	717	665	2000
100L+70R	1700	1692-1708	508	476	702	915	717	690	2000




















































LUNAR F

MEXEN

DRZWI WNĘKOWE ZE ŚCIANKĄ BEZ LISTWY



[PL] Instrukcja montażu [EN] Assembly Instructions [DE] Montageanleitung [FR] Instructions de montage [IT] Istruzioni di montaggio [ES] Instrucciones de montaje [NL] Montage-instructies [RU] Инструкция по монтажу [SV] Monteringsanvisning [NO] Monteringsanvisning [DA] Monteringsvejledning [FI] Asennusohje [CS] Montážní návod [PT] Instruções de montagem [HU] Szerelési útmutató [RO] Instrucțiuni de montaj [EL] Οδηγίες συναρμολόγησης [SK] Návod na montáž [UK] Інструкція з монтажу [HR] Upute za montažu [LT] Montavimo instrukcija [BG] Инструкция за монтаж [SL] Navodila za montažo [LV] Montāžas instrukcija [ET] Paigaldusjuhend [SR] Упутство за монтажу [IS] Samsetningarleiðbeiningar [SQ] Udhëzime për montim [MK] Инструкции за монтажа [MT] Istruzzjonijiet għall-assemblaġġ





[1]



X1

[2]



X1

[3]



X1



X1

[4]



X2

[5]



X2

[6]



X1

[7]



X2

[8]



X1

[9]



ST3.9X40

X8

[10]



Ø 8

X8

[11]



X1

[12]



X1

[13]



X1



X1

[14]



ST3.5X32

X2

[15]



Ø 6


X2

[16]



X1

[17]



X1

X1

[18]



X2

[19]



X1

[20]



X2

[21]











X1

[22]



X4



$$X=B+C+D+9+7+20+2$$

Model	A	X	B	C	D	E	F	G	H
60L+50R	1100	1092-1100	276	276	502	520	517	490	2000
65L+50R	1150	1142-1150	301	301	502	569	517	515	2000
70L+50R	1200	1192-1200	326	326	502	619	517	540	2000
75L+50R	1250	1242-1250	351	351	502	668	517	565	2000
80L+50R	1300	1292-1300	376	376	502	718	517	590	2000
85L+50R	1350	1342-1350	401	401	502	766	517	615	2000
90L+50R	1400	1392-1400	426	426	502	816	517	640	2000
95L+50R	1450	1442-1450	451	451	502	866	517	665	2000
100L+50R	1500	1492-1500	476	476	502	915	517	690	2000
60L+60R	1200	1192-1200	276	276	602	520	617	490	2000
65L+60R	1250	1242-1250	301	301	602	569	617	515	2000
70L+60R	1300	1292-1300	358	326	602	619	617	540	2000
75L+60R	1350	1342-1350	383	351	602	668	617	565	2000
80L+60R	1400	1392-1400	408	376	602	718	617	590	2000
85L+60R	1450	1442-1450	433	401	602	766	617	615	2000
90L+60R	1500	1492-1500	458	426	602	816	617	640	2000
95L+60R	1550	1542-1550	483	451	602	866	617	665	2000
100L+60R	1600	1592-1600	508	476	602	915	617	690	2000
60L+70R	1300	1292-1300	276	276	702	520	717	490	2000
65L+70R	1350	1342-1350	301	301	702	569	717	515	2000
70L+70R	1400	1392-1400	358	326	702	619	717	540	2000
75L+70R	1450	1442-1450	383	351	702	668	717	565	2000
80L+70R	1500	1492-1500	408	376	702	718	717	590	2000
85L+70R	1550	1542-1550	433	401	702	766	717	615	2000
90L+70R	1600	1592-1600	458	426	702	816	717	640	2000
95L+70R	1650	1642-1650	483	451	702	866	717	665	2000
100L+70R	1700	1692-1700	508	476	702	915	717	690	2000

